Installation Guidance

Vandal-resistant shower arm and head

B&M SKU ID08431 | Idral code 08431

Installation sequence

1. Have a qualified installer follow the original model diagrams and prepare the water connections. Purge the supply pipes before connection and provide suitable water filtration.

2. Following ISTA09-01 Figure 01, screw the flanged water-supply joint to the ½-inch inlet, fit the shower arm and tighten the upper retaining screw.

3. Open the supply, inspect the joints for leaks and check the head movement and water pattern.

Important

Follow the Technical Specification operating limits: 0.5–6 bar and 5–65 °C.

Source: Idral ISTA09-01. This summary accompanies the original manufacturer instructions supplied separately. Read the original instructions for complete safety information, model diagrams and service procedures.