Installation Guidance

Movable anti-limescale shower head

B&M SKU ID08431/1 | Idral code 08431/1

Installation sequence

1. Have a qualified installer follow the original model diagrams and prepare the water connections. Purge the supply pipes before connection and provide suitable water filtration.

2. Fit the movable head to a compatible shower-arm assembly using the model drawing. The flanged wall joint and arm sequence in ISTA09-01 applies to the complete assembly.

3. Open the supply, inspect the joints for leaks and check the head movement and water pattern.

Important

Follow the Technical Specification operating limits: 0.5–6 bar and 5–65 °C.

Source: Idral ISTA09-01. This summary accompanies the original manufacturer instructions supplied separately. Read the original instructions for complete safety information, model diagrams and service procedures.