

INSTALLATION INSTRUCTIONS

Complete Assembly Kit for WHB

B&M SKU: **ID10191PLT** Idral code: **B&M; complete assembly kit**

Before installation

Inspect the product and all supplied components. Confirm the model, dimensions, installation position and compatibility of taps, waste and plumbing. Protect finished surfaces and isolate the water supply where applicable.

Installation sequence

1. Confirm that the wall structure and chosen fixings can safely support the complete assembly and basin in use.
2. Assemble the supplied galvanized support and adjustment components in their intended configuration. Do not substitute or omit structural parts.
3. Set out the assembly level and at the required user height. Mark fixing positions using the actual assembly as the template.
4. Install suitable structural wall fixings selected by the competent installer. Fixings are not assumed to be included.
5. Fit the compatible washbasin to the complete assembly, then connect the tap, waste and siphon/trap separately.
6. Operate the adjustment mechanism through its full travel. Confirm secure fixing, free movement, stability and leak-free plumbing before use.

Important

Installation must be carried out by a competent installer. Site conditions determine the required structural fixings. Stop work if the product is damaged, dimensions do not match, or the supporting construction is unsuitable.

Retain the official technical specification and proof of purchase. Damage caused by unsuitable cleaners, impact, incorrect installation or incompatible components is not a manufacturing defect.