

INSTALLATION INSTRUCTIONS

Dinan Square Natural | Product code: BAT4115/CRU

Before you begin

Installation must be completed by a competent installer. Inspect the basin and compare it with the technical specification before fitting. Do not install a damaged product.

Confirm the installation

This basin is designed for countertop installation. Confirm a flat, rigid, water-resistant support and suitable service positions for the 385 x 385 x 135 mm product.

- 1 Plan services. Confirm the waste position, tap reach, clearances and access for maintenance.
- 2 Select fittings. Use a basin waste suitable for a basin without overflow and an accessible compatible siphon or trap.
- 3 Prepare support. For countertop fitting, form only the required service openings. For wall-hung products, use the factory mounting points and verified structural support; never drill or alter the porcelain.
- 4 Dry-fit. Confirm alignment, stability, tap operation and connection access before sealing.
- 5 Bed and seal. Use compatible neutral-cure sanitary silicone. Do not create point loads or over-tighten fittings.
- 6 Connect and test. Have a competent plumber connect the tap, waste and siphon/trap. Test for leaks and free drainage; allow sealant to cure fully.

**SOLD
SEPARATELY**

Tap or mixer, basin waste, siphon/trap, mounting fixings, sealants, support/countertop and plumbing connections are sold separately unless expressly included.