

INSTALLATION INSTRUCTIONS

Oropesa Back-to-Wall Rimless WC | Product code: BAT4566

Before you begin

Installation must be completed by a competent installer in accordance with local building and plumbing requirements. Inspect the WC and compare it with the current technical specification before fitting. Do not install a damaged product.

Confirm the installation

This is a floor-standing back-to-wall WC requiring a compatible concealed cistern and flush plate. Confirm the soil connection, water inlet, service access, finished wall and floor, and 540 x 360 x 415 mm WC dimensions before installation.

- 1 Select and position the concealed cistern and flush plate. Follow the system manufacturer's structural, service-access and finished-wall requirements.
- 2 Plan services. Verify the selected outlet arrangement, pan connector, flush-pipe alignment and water inlet before closing the wall.
- 3 Dry-fit the pan. Position it level against the finished wall, confirm all connector projections and mark only verified floor-fixing locations.
- 4 Connect the outlet and flush pipe without strain, distortion or obstruction, following each component manufacturer's instructions.
- 5 Secure the pan with suitable mechanical floor fixings where specified. Tighten evenly and never point-load or over-tighten the porcelain.
- 6 Seal and commission. Apply neutral-cure sanitary silicone at the wall and floor junctions as appropriate, flush repeatedly and inspect every connection for leaks.
- 7 Fit and adjust the supplied soft-close seat and cover. Allow sealant to cure fully before use.

SOLD SEPARATELY

Compatible concealed cistern, flush plate, connection components, installation fixings, sealants and plumbing connections are sold separately unless expressly included in the order.

These instructions provide general guidance. The current Bathco technical specification and the instructions for every selected installation system take precedence.